

## **SPORT★** How to Fit Your SportStar ChinStrap - Standard Helmet

To see a video of this process, visit [sportstargear.com/chinstrap-fitting](http://sportstargear.com/chinstrap-fitting)



**Step 1:**  
Have player firmly hold chinstrap **centered** on his chin.



**Step 2:**  
Adjust and fasten top straps first. Slide the buckles to line up with the snap post on the helmet. While adjusting, make sure **chinstrap is remaining centered on player's chin**.



**Step 3:**  
Adjust the bottom strap buckles by repeating Step 2.



**Step 4:**  
Check fit by holding helmet by face mask and attempting to move helmet side to side and up and down. There should be no sliding or movement of the helmet. **Fit should be snug with equal pressure on both sides of chin.**

## **SPORT**★ Helmets with Sliding Connection Switched to Strap Adapters

To see a video of this process, visit [sportstargear.com/chinstrap-fitting](https://sportstargear.com/chinstrap-fitting)



**Step 1:**  
Remove the Cam Loc by unscrewing the thumbwheel on the inside of the helmet and sliding the strap free.



**Step 2:**  
Install the Strap Adapter by setting it in the same place the Cam Loc was and fastening it snugly with the thumbwheel. Slide on the buckle to the strap to prepare for fitting.



**Step 3:**  
Have the player firmly hold the chinstrap to the center of their chin.



**Step 4:**  
Adjust and fasten top straps first. Slide the buckles to line up with the snap post on the helmet. **While adjusting, make sure chinstrap is remaining centered on player's chin.**



**Step 5:**  
Adjust the bottom strap buckles by repeating Step 2.



**Step 6:**  
Check fit by holding helmet by face mask and attempting to move helmet side to side and up and down. There should be no sliding or movement of the helmet. **Fit should be snug with equal pressure on both sides of chin.**

## **SPORT** ★ Helmets with Sliding Connection Switched to New QuickClick

To see a video of this process, visit [sportstargear.com/chinstrap-fitting](https://sportstargear.com/chinstrap-fitting)



**Step 1:**  
Remove the Cam Loc by unscrewing the thumbwheel on the inside of the helmet and sliding the strap free.



**Step 2:**  
Install the base of the QuickClick by setting it in the same place the Cam Loc was and fastening it snugly with the thumbwheel. Unclick the tongue end to be secured while fitting the chinstrap.



**Step 3:**  
Have the player firmly hold the chinstrap to the center of their chin.



**Step 4:**  
Adjust and fasten top straps first. Slide the buckles to line up with the snap post on the helmet. **While adjusting, make sure chinstrap is remaining centered on player's chin.**



**Step 5:**  
Pull the bottom strap snug and mark where the strap meets the front edge of the QuickClick base.



**Step 6:**  
Loop the strap through the top slot and back under the bottom slot. Adjust the placement of the strap so the mark you made in Step 5 is showing on the bend. Snugly screw in the security screw on the underside to ensure the strap stays in place. Routine checking of the screws tightness is recommended throughout the season.



**Step 7:**  
Click the strap adapter together to check the fit and placement of the chinstrap cup.



**Step 8:**  
Check fit by holding helmet by face mask and attempting to move helmet side to side and up and down. There should be no sliding or movement of the helmet. **Fit should be snug with equal pressure on both sides of chin.**



## How to Fit Your SportStar ChinStrap - Xenith Helmet

To see a video of this process, visit [sportstargear.com/chinstrap-fitting](http://sportstargear.com/chinstrap-fitting)



**Step 1:**  
Have player firmly hold chinstrap **centered** on his chin.



**Step 2:**  
Adjust and fasten top straps first. Slide the buckles to line up with the snap post on the helmet. While adjusting, make sure **chinstrap is remaining centered on player's chin**.



**Step 3:**  
Adjust the bottom strap buckles by repeating Step 2.



**Step 4:**  
Check fit by holding helmet by face mask and attempting to move helmet side to side and up and down. There should be no sliding or movement of the helmet. **Fit should be snug with equal pressure on both sides of chin.**